User manual



Insert the TF card: unscrew the pen holder and insert the TF card into the card slot. (Note: Please insert or remove the TF card when turn off.)

Charging: USB cable connect pen camera and computer or power bank to charge. If you use charger, it is recommended to use a current less than 1A.

Copy file: use USB cable connect pen camera and computer, open the removable disk,find file,copy and save the file in computer, then you can play it.

Function

Turn on: No card:long press power button 4 seconds,yellow light on and then off,red light blinking 10times and off. With card:long press power button 4 seconds,yellow light keep on and standby .

Turn off: long press power button 5 seconds, red light blinking 3 times and off, green light on and then off.

Record video: In standby mode,long press power button 2 seconds, yellow light blinking 3 times and off then start recording, video esolution: 1920*1080. one file 20min .loop recording.

Stop record: short press power button , yellow light on ,save file and enter standby.

Take photo: in standby mode,short press power button ,yellow light blinking one time , take on picture. Resolution:2560*1440.

Recoding when charge: with or without TF card,yellow light on , red light slowly blinking for charging, full charge: yellow and red light keep on,Voltage: 4.1-4.2V, remove USB after turn off camera.other operation is same as common, red light slowly blinking when charging.

Reset: press reset button at any time. Pls know that the recording file won't save.

Low battery: low battery voltage 3.3V, red and yellow light blinking 3 times and off, camera save file and turn off .

Standby: in standby ,camera will turn off after 60seconds if no operation.

File format: Audio, photo,video, time. Camera will turn off when remove TF card.

Time: revise "time" file accord this format (such as 2019-06-01 00:00:00Y), and save the file , it will record with update time show when restart next time. revise "time" file accord this format (such as 2019-06-01 00:00:00N), and save the file , it will record without time shows when restart next time.

Precautions:

Warning: Failure to follow the safety instructions may result in injury and danger.

Do not use this product in a particularly hot, cold, dusty or humid environment.

Do not put this product in water or other liquids.

Do not expose this product to sunlight or put it in a fire to avoid battery explosion and fire.

Do not place this product where children can reach it to avoid injury to children.

Do not drop or violently hit the product, otherwise it will cause damage to the parts and cause the product to not work normally.

Do not disassemble this product to avoid damage to parts.

If you do not use it for a long time, please charge the product once every two months.

special reminder

Note that the data should be backed up separately to avoid data loss.

Please read the manual before using this product. If data is lost due to human operation or force majeure, the company is not responsible for it.