D7 英文说明书

正面


Digital Camera Manual
English
Introduction
Shutter button
Mode button
Power button
Micro SD card slot
Charging indicator
Reset button
Important note
Camera Function
Photo Mode
Press the Setting button once
Photo mode: Capture a photo by pressing the shutter button.
Photo mode: Capture a photo by pressing the shutter button.
Photo mode: Capture a photo by pressing the shutter button.