

INSTALLATION INSTRUCTION

1



Insert the screw of the light ring into the bottom seat hole as shown in the figure.

2



Pay attention to the order of nuts and washers as shown in the figure, and tighten the nuts to the direction shown in the figure.

3



Connect the water pump to the pre installed hose as shown in the figure.

4



As shown in the figure, insert the LED light beads on the water pump into the light holes on the back of the iron plate.

5



Finally, plug in two plugs and power on.