


CHARGING GRIP
WITH 1500mAh BATTERY
FOR SWITCH2 JOYCON



User Manual
产品说明书
HS-SW2043

JoyCon2手柄接口
JoyCon2 Port

充电指示灯
Charging Indicator

手柄通道映射灯
JoyCon2 Channel Indicator

单击开启
关闭充电宝
Click to turn on
/ off the power bank

内置电池指示灯
Built-in-Battery Indicator

充电接口
Power Input Port


拆卸扣
Release Button

产品属性

1、专为Switch2Joy-Con手柄充电
2、符合人体工学，握把处采用防滑设计，大幅提升握持感。
3、充电指示显示，可同时给2个Joy-Con手柄充电
4、内置1500mAh锂电池
5、内置NTC保护电路，电池充电时提供过热保护；
6、内置智能芯片，可以过流、过压和短路等多重安全防护

操作指引

用配送的TYPE C线连接到握把，USB A连接到5V/2A的适配器，给握把内置电池充电。充电时蓝色指示灯闪烁，充满后4个蓝色指示灯常亮，内置充电完成。
将joy-con手柄插入对应的L（左），R（右）接口充电亮红灯，充满亮绿灯，充满后1分钟绿灯灭。



内置电池指示灯：25%-50%-75%-100%

产品参数

输入直流电压:5V
输入电流：2A
输出电压：5V
Joy-Con充电电流：250mA*2
内置电池：1500mAh
内置电池充电电流：约1A


— 1 —

Features

1、Designed for Charging Switch 2Joy-Con Controllers.
2、Ergonomically designed with non-slip grip texture, significantly improving comfort and hold.
3、Charging status indication, can charge 2 Joy-Con controllers simultaneously.
4、Built-in 1500mAh Li-ion battery.
5、Built-in NTC protection circuit provides overheating protection during battery charging and discharging.
6、Built-in smart IC provides multiple safety protections including over-current, over-voltage, and short-circuit protection.

Operating Instructions

Use the provided Type-C cable to connect the Grip. Connect the USB A end to a 5V/2A adapter to charge the Grip's built-in battery. The blue indicator blinks during charging. All 4 blue indicators stay solid when the internal battery is fully charged.
Insert Joy-Con controllers into the corresponding L (Left) and R (Right) ports for charging. The indicator lights red while charging, turns green when fully charged, and turns off after being fully charged for 1 minute.



Built-in-Battery Indicator：25%-50%-75%-100%

— 2 —

Electrical Parameters

Input DC Voltage: 5V
Input Current: 2A
Output Voltage: 5V
Joy-Con Charging Current: 250mA*2
Built-in Battery: 1500mAh
Built-in Battery Charging Current: About 1A

— 3 —

产品型号:HS-SW2043 单页尺寸100*70mm
材质:80G书写纸 印刷:单色双面印刷3折页