

Congratulations on purchasing your new reer humidifier. The humidifier consists of an ultrasonic humidification module with a built-in night light and a remote control. We are confident that you will enjoy the quality of our product for many years to come. Please take a few minutes to read the safety instructions thoroughly. The reer humidifier can only be used safely if all the points listed here are observed. Please keep the user manual in a safe place for future reference.

Technical specifications

Item:	94060 Humidifier
Power:	28W
Operating voltage:	230V
Protection class:	IPX0
Dimensions (WxHxD):	185 x 290 x 185 mm
Water tank capacity:	5.5 l
Mist output:	max. 300 ml/h
Maximum room size:	30 m²
Noise level:	≤ 40 dBA (1 m)
Cable length:	125 cm

Contents

1x humidifier, 1x remote control including 1x CR2025 battery

General safety instructions

- ! Check the device for obvious damage before each use. If you notice any damage, do not use this device.
- ! Ensure that the mains voltage at the socket matches that of the device. Check, particularly when travelling abroad, that the local mains voltage corresponds to the voltage specified on the device.
- ! Do not open the appliance, with the exception of the water tank lid, as this may result in electric shock. If the appliance is not working properly, please DO NOT attempt to fix the problem yourself. In this case, please contact your retailer.
- ! This product is not a toy. Do not allow your children to play with the appliance.
- ! Keep the appliance out of the reach of children under 8 years of age.
- ! This appliance is suitable for use by children aged 8 years and over and by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, provided they are supervised or have been given instructions on how to use the appliance safely and understand the risks involved.
- ! Cleaning and user maintenance must not be carried out by children under 8 years of age or without supervision.
- ! The socket for connecting the mains adapter must be located near the device and be freely accessible at all times.
- ! Disconnection from the mains supply is only guaranteed if the power adaptor is unplugged from the socket.
- ! The night light bulb cannot be replaced; once the bulb has reached the end of its service life, it cannot be replaced.
- ! The humidifier must be emptied, cleaned and dried before storage. The humidifier must be cleaned again before its next use.
- ! Do not leave any water in the reservoir when the appliance is not in use. Disconnect the appliance from the mains when not in use.
- ! Warning: Microorganisms that may be present in the water or in the environment where the device is used or stored can grow in the water tank and be blown into the air. Failure to change the water and clean the tank properly every 3 days can therefore pose serious health risks.
- ! Please use the product only for its intended purpose.
- ! Use the device exclusively for private indoor use; it is not intended for commercial use.
- ! Use the device only in an upright position.
- ! Avoid extreme heat and direct sunlight.
- ! Caution: Please note that high humidity can promote the growth of biological organisms in the surrounding area.
- ! Please note that the area around the humidifier must not become damp or wet. If dampness occurs, reduce the humidifier's output. Ensure that absorbent items such as rugs, curtains, net curtains or tablecloths do not become damp.
- ! Please use a properly connected socket for the appliance. If the socket is not properly connected, the appliance's plug will become hot.

Start-up

Connect the reer humidifier to the mains using the power cable. Open the water tank lid and fill the water tank with sufficient tap water. It is essential to ensure that no water enters the covered air outlet inside the water tank and that the amount filled does not exceed the maximum fill level mark. The humidifier can only be switched on if there is sufficient water in the water tank.

Description of display symbols



Functions

-  **ON/OFF:**
Switches the humidifier on and off.
-  **Humidifier / Fog meter:**
You can choose between 4 intensity levels (0/1/2/3) for the humidifier. At level 0, humidification is deactivated.
-  **Humidity / Constant Humidity:**
This function allows you to set your desired humidity level in 5% increments (40%–90%) in the room. Once this humidity level is reached, the humidifier switches off automatically. If the humidity falls below the set value, the humidifier switches back on automatically.
-  **Timer:**
The timer can be set to 1, 2, 4 or 8 hours. If none of the timer icons are lit, the humidifier is in continuous operation.
-  **Night light:**
The colour-changing night light can be switched on and off using this button on the remote control. On the unit itself, the night light can be switched on and off by holding down the timer button.
-  **Sleep mode:**
In sleep mode, the LED display on the device is switched off, but the other functions remain active. You can switch this mode on and off on the remote control using this button. On the device itself, sleep mode can be activated and deactivated by holding down the On/Off button.

Cleaning and maintenance

- ! The tank must be cleaned and refilled with fresh water at least every 3 days.
- ! Always unplug the power supply from the mains socket before cleaning the device.
- ! Use only a slightly damp cloth.
- ! Do not immerse the device in water.
- ! Do not use any chemical cleaning agents.
- ! Warning: Repairs to the device must only be carried out by qualified personnel.

Environmental information

-  At the end of its service life, this product must not be disposed of with normal household waste. Owners of old appliances are obliged to hand them in at a collection point for the recycling of electrical equipment. Please ask your local council for details of the relevant disposal point. Small appliances with a maximum edge length of less than 25 cm may, where applicable, be handed in at electrical retailers. Batteries and rechargeable batteries must be removed from the appliance, provided this can be done without damaging the device, and handed in separately at a collection point for batteries and rechargeable batteries. The symbol on the product, in the user manual or on the packaging indicates these obligations.

Warranty

Please keep your proof of purchase, user manual and product reference number. Any warranty claims or claims arising from guarantee commitments must be dealt with exclusively through the retailer. All technical data, information and specifications relating to the product described in this manual have been compiled to the best of our knowledge and are correct at the time of publication. The information provided by reer is intended to be accurate and reliable. However, reer accepts no liability for any errors in this document and reserves the right to make changes to the product design or specifications without prior notice. Reproduction and distribution of information from this copyright-protected work in any form or by any means, whether graphic, electronic or mechanical, by photocopying, recording on tape or storing in a data retrieval system, even in part, require the prior written permission of reer.

reer GmbH
Mühlstr. 41
71229 Leonberg
Germany
www.reer.de



Rev. 015022

Congratulations on purchasing your new reer humidifier. The humidifier comprises an ultrasonic humidification module with a built-in night light and a remote control. We are confident that you will enjoy the quality of our product for many years to come. Please take a few minutes to read through the safety instructions carefully. You will only be able to use the Reer humidifier with confidence if all the points mentioned here have been checked. Please keep the instruction manual in a safe place for future reference.

Technical data

Item:	94060 Humidifier
Power:	28W
Operating voltage:	230V
Protection rating:	IPX0
Dimensions (WxHxD):	185 x 290 x 185 mm
Water tank capacity:	5.5 l
Nebuliser output	max. 300 ml/h
Maximum room size:	30 m ²
Noise level:	≤ 40 dBA (1 m)
Cable length:	125 cm

Contents:

1x humidifier, 1x remote control incl. 1x CR2025 battery

General safety instructions

- ! Check the unit for visible damage before each use. If you notice any damage, do not use the unit.
- ! Ensure that the operating voltage of the power socket matches that of the mains adapter. Check, particularly when travelling abroad, whether the local mains voltage corresponds to the voltage specified on the devices or the mains adapters.
- ! With the exception of the water tank lid, the device must not be opened, as this may result in electric shocks. If the device malfunctions, please do NOT attempt to repair it yourself. Please contact your dealer in this case.
- ! This product is not a toy. Do not allow children to play with the device.
- ! Keep the device and its power cable out of reach of children under 8.
- ! This device is suitable for use by children over the age of 8 and people with reduced physical, sensory or mental capabilities, or with very little experience and knowledge, provided that they are supervised or have been instructed on how to use the device safely and have understood the associated risks.
- ! Cleaning and user maintenance should not be carried out by children under 8 or without supervision.
- ! Disconnection from the mains supply is only guaranteed if the mains adapter is removed from the socket.
- ! The bulb in the snooze lamp is not replaceable; once the bulb has reached the end of its life, it cannot be replaced.
- ! The humidifier must be emptied, cleaned and dried before storage. The humidifier must be cleaned again before the next use.
- ! Do not leave any water in the storage tank when the device is not in use. Unplug the device from the mains when not in use.
- ! Warning: Micro-organisms that may be present in the water or in the environment where the device is used or stored can grow in the water tank and be blown into the air. This can therefore lead to serious health risks if the water is not refilled and the water tank is not properly cleaned every 3 days.
- ! Please use the device only for its intended purpose.
- ! The product is for personal indoor use only and is not intended for commercial use.
- ! Only use the device in an upright position.
- ! Avoid extreme heat and direct sunlight.
- ! Caution: Please note that high humidity can promote the growth of biological organisms in the environment.
- ! Ensure that the air intake and outlet are not obstructed. Therefore, do not place any objects on top of or in front of the device.
- ! Please note that the area around the humidifier must not become damp or wet. If moisture is present, reduce the humidifier's output. Ensure that no absorbent materials such as carpets, curtains, drapes or tablecloths become damp.
- ! Please use a properly fitted socket for the device. If it is not properly fitted, the device's plug will become hot.

Before first use

Connect the reer humidifier to the mains using the power cable. Open the water tank lid and fill the water tank with sufficient tap water. When doing so, ensure that no water enters the covered air outlet inside the water tank and that the amount filled does not exceed the maximum fill level. The humidifier can only be switched on if there is sufficient water in the water tank.

Description of symbols / display



Functions

- ON/OFF:**
Switches the humidifier on and off.
- Humidifier / Fog meter:**
You can choose between 4 intensity levels (0/1/2/3) for the humidifier. Humidification is deactivated at level 0.
- Humidity / Constant humidity:**
With this function, you can set the desired humidity in the room in 5% increments (40%–90%). The humidifier switches off automatically as soon as this humidity level is reached. If the humidity falls below the set value, the humidifier switches on again automatically.
- Timer:**
The timer can be set to 1, 2, 4 or 8 hours. If none of the timer icons is lit, the humidifier is running continuously.
- Night light:**
The colour-changing night light can be switched on and off using this button on the remote control. The night light can be switched on and off directly on the device by pressing and holding the timer button.
- Snooze mode:**
In snooze mode, the LED display on the unit is switched off, but the other functions remain active. You can switch this mode on and off using this button on the remote control. Snooze mode can be activated and deactivated directly on the device by pressing and holding the On/Off button.

Cleaning and maintenance

- ! The tank must be cleaned and refilled with fresh water at least every 3 days.
- ! Always unplug the power supply from the mains socket before cleaning the unit.
- ! Use only a slightly damp cloth.
- ! Do not immerse the device in water.
- ! Do not use chemical cleaning agents.
- ! Caution: Repairs to the device must be carried out by qualified personnel only.

Environmental protection

-  At the end of its useful life, this product must not be disposed of with normal household waste. Owners of old devices are required to hand them in at a collection point for the recycling of electronic devices. Please contact your local council to find out more about a suitable disposal centre. It may be possible to hand in small devices with a maximum edge length of less than 25 cm at an electrical retailer. The relevant symbol on the product, in the user manual or the packaging refers to these obligations.

Warranty

Please retain your receipt, the user manual and item number. Warranty claims or claims arising from guarantees must be processed by the dealer. The technical specifications, information and characteristics of the product described herein have been compiled to the best of our knowledge and belief and are correct at the time of printing. Any information provided by reer should be correct and authoritative. Nevertheless, reer accepts no liability for any errors in this document and reserves the right to make changes to the product design and/or specifications without prior notice. Reproduction and disclosure of information contained in this copyright-protected document, in any form or by any means – whether graphic, electronic or mechanical, including photocopying, recording on tape or storage in a data retrieval system (even in part) – require prior written consent from reer.

reer GmbH
Mühlstr. 41
71229 Leonberg
Germany
www.reer.de



Rev. 015022

FR Air humidifier

Instructions for use // Item no. 94060

Congratulations on purchasing your new humidifier. The humidifier consists of an ultrasonic humidification unit with a built-in night light and a remote control. We are confident that you will enjoy the quality of our product for many years to come. Please take a few minutes to read the safety instructions carefully. Provided all the points mentioned here are followed, the reer humidifier can be used with complete peace of mind. Please keep this user manual in a safe place so that you can refer to it later.

Technical specifications

Item:	94060 Air Humidifier
Power:	28W
Voltage:	230V
Protection rating:	IPX0
Dimensions (WxHxD):	185 x 290 x 185 mm
Tank capacity:	5.5 l
Mist output:	max. 300 ml/h
Maximum room size:	30 m²
Noise level:	≤ 40 dBA (1 m)
Cable length:	125 cm

Contents of delivery

1 x air humidifier, 1 x remote control with 1 x CR2025 battery


General safety instructions

- ! Before each use, check that the appliance has no visible defects. If you notice any defects, do not use the appliance.
- ! Ensure that the voltage of the mains socket matches that of the adapter. Check, particularly when travelling abroad, that the local voltage matches that of the device or the adapter.
- ! Apart from the water tank lid, the appliance must not be opened, as there is a risk of electric shock. If the appliance is faulty, DO NOT attempt to fix the problem yourself. In this case, please contact your retailer.
- ! This item is not a toy. Do not allow children to play with the appliance.
- ! Keep the appliance and its power cable out of the reach of children under 8 years of age.
- ! This appliance may be used by children aged 8 years and over and by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, only if they are supervised or have been instructed on how to use the appliance and understand the risks involved.
- ! Cleaning and maintenance must not be carried out by children under 8 years of age or without supervision.
- ! Disconnection from the mains supply is only guaranteed when the plug is unplugged. The light source in this night light cannot be replaced; when the light source reaches the end of its life, it cannot be replaced.
- ! The humidifier must be emptied, cleaned and dried before being stored. Before first use, the humidifier should be washed again.
- ! Do not leave water in the tank if the appliance is not in use. If not in use, unplug the appliance.
- ! Warning: Microorganisms that may be present in the water or the environment where the device is used or stored can grow in the tank and be released into the air. This may therefore pose serious health risks if the water is not changed and the tank is not cleaned every 3 days.
- ! Please use this product only for the purpose for which it was designed.
- ! This appliance is intended solely for private indoor use and not for commercial use.
- ! Use the appliance in an upright position only.
- ! Avoid exposing the device to extreme heat or direct sunlight.
- ! Please note: High humidity levels may encourage the growth of microorganisms in the environment.
- ! Do not place any objects on top of or in front of the unit, as this may obstruct the air intake and outlet.
- ! Please note that the area around the humidifier must not be damp or wet. If the area becomes damp, reduce the humidifier's output. Ensure that no absorbent materials such as carpets, curtains, net curtains or tablecloths become damp.
- ! Use a properly fitted socket for this appliance to avoid any risk of the plug overheating.

Start-up

Connect the Reer humidifier to the power cable. Open the tank lid and add enough tap water to the tank. Ensure that no water enters the tank through the covered air outlet, and that the water level does not exceed the maximum level indicator. Only switch on the humidifier if there is enough water in the tank.

Description of the symbols displayed on the screen



Function s

- ON/OFF:**
Use the humidifier's switch.
- Air humidifier / mist setting:**
You can choose between 4 intensity levels (0/1/2/3) for the air humidifier. At level 0, air humidification is disabled.
- Air humidity / Constant humidity:**
This function allows you to humidify the air in 5% increments, (40%-90%) in the room. Once this humidity level is reached, the humidifier switches off automatically. If the humidity falls below this level, the humidifier switches back on automatically.
- Timer:**
You can set the timer to 1, 2, 4 or 8 hours. If none of the timer icons are lit, the humidifier is running continuously.
- Night light:**
The colour-changing night light is switched on and off using this button on the remote control. The night light can also be switched on and off directly on the unit by holding down the timer button.
- Sleep mode:**
In sleep mode, the device's LED is switched off, whilst the other functions remain active. On the remote control, you can switch this mode on and off using this button. Sleep mode can be switched on and off directly on the device by holding down the On/Off button.

Cleaning and maintenance

- ! The tank must be cleaned every 3 days and refilled with clean water.
- ! Always unplug the power supply from the mains socket before cleaning the appliance.
- ! Use only a slightly damp cloth.
- ! Do not immerse the appliance in water.
- ! Do not use chemical cleaners.
- ! Warning: repairs to the appliance must only be carried out by qualified personnel.

Environmental information

- At the end of its useful life, this product must not be disposed of with household waste. Old appliances must be taken to a collection point for the recycling of electrical appliances. Please contact your local council to find out which centres are responsible for waste management. Small appliances with a maximum side length of 25 cm may be handed in at an electronics shop. These obligations are indicated by the symbol on the product, in the instructions for use or on the packaging.

Warranty

Please retain your proof of purchase, the user manual and the item number. Any warranty claims or disputes regarding the warranty must be settled exclusively with the retailer. The technical specifications, information and product details provided on these pages are given in good faith and reflect the current state of the art. The information provided by reer is intended to be accurate and reliable. However, reer cannot accept any liability for any errors in this document and reserves the right to make changes to the design or product specifications without prior notice. Any reproduction or transmission to any third party of the information contained in this document, which is protected under copyright law, in any form whatsoever, whether graphic, electronic or mechanical, including by photocopying, tape recording or Storage in a search system (even in part) requires the prior written consent of reer.

reer GmbH
Mühlstr. 41
71229 Leonberg
Germany
www.reer.de

Rev. 015022



IT Air humidifier

Instructions for use // Item no. 94060

We would like to congratulate you on the purchase of your new reer humidifier. The humidifier consists of an ultrasonic unit with a built-in soft light and a remote control. We are confident that you will be satisfied with the quality of our product. Please take the time to read the safety instructions carefully. Only if all the points listed here are followed can the reer humidifier be used without any concerns. Please keep the user manual in a safe place for future reference.

Technical specifications

Item:	94060 Air Humidifier
Power:	28W
Operating voltage:	230V
Protection rating:	IPX0
Dimensions (WxHxD):	185 x 290 x 185 mm
Tank capacity:	5.5 l
Mist output:	max. 300 ml/h
Maximum room size: 30 m²	
Noise level:	≤ 40 dBA (1 m)
Cable length:	125 cm

Contents

1 humidifier, 1 remote control incl. 1 CR2025 battery

General safety warnings

- ! Before each use, check the appliance for any visible damage. If damage is found, the appliance must not be used.
- ! Ensure that the mains voltage at the socket matches that of the power supply unit. Check, Especially when travelling abroad, ensure that the local mains voltage corresponds to the voltage indicated on the appliances or power adapters.
- ! The appliance, with the exception of the tank lid, must not be opened to avoid the risk of electric shock. If the appliance malfunctions, DO NOT attempt to repair it yourself. In such cases, we recommend that you contact your retailer.
- ! This product is not a toy. Ensure that children do not play with the appliance.
- ! Keep the appliance and its power cord out of the reach of children under 8 years of age.
- ! This appliance is suitable for use by children aged 8 years and over and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, provided they are supervised or have been instructed on how to use the appliance safely and have understood the associated risks.
- ! Cleaning and maintenance by the user must not be carried out by children under 8 years of age or without supervision.
- ! Disconnection from the mains supply is only guaranteed if the power supply unit is unplugged from the socket.
- ! The light source for the soft lighting cannot be replaced; therefore, once it has reached the end of its service life, it cannot be replaced.
- ! Before storing the humidifier, it must be emptied, cleaned and dried. The humidifier must be cleaned again before its next use.
- ! When the appliance is not in use, do not leave any water in the tank. When not in use, unplug the appliance from the mains.
- ! Warning: Microorganisms that may be present in the water or in the environment where the appliance is used or stored can grow in the tank and be released into the air. Therefore, if the water is not changed and the tank is not cleaned properly every 3 days, there are serious health risks.
- ! Use the product only for its intended purpose.
- ! Use the appliance exclusively for private indoor use; it is not intended for commercial use.
- ! Use the appliance in an upright position only.
- ! Do not expose to extreme heat or direct sunlight.
- ! Caution: please note that high humidity can encourage the growth of biological organisms in the room.
- ! The air inlet and outlet must not be covered. Therefore, do not place any objects on top of or in front of the appliance.
- ! Ensure that the room in which you use the appliance does not become too damp or even wet. If dampness is present, reduce the humidifier's output. Ensure that fabric items, such as carpets, curtains, drapes or tablecloths, do not become damp.
- ! Ensure the appliance is connected to a suitable power socket. If the connection is unsuitable, the appliance's socket will become hot.

Setting up

Connect the reer humidifier to the mains using the power cable. Open the tank lid and fill the tank with a sufficient amount of tap water. When doing so, take great care to ensure that no water enters the covered air inlet inside the tank and that the amount poured in does not exceed the maximum level mark. The humidifier will only switch on if there is a sufficient amount of water in the tank.

Description of symbols on the display



Functions

- ON/OFF:** Switches the humidifier on and off.
- Humidifier / Fog meter:** You can choose from 4 intensity levels (0/1/2/3). At level 0, the humidifier is switched off.
- Humidifier / Constant Humidity:** With this function, you can set the desired room humidity in increments of 5% (40%–90%). As soon as the desired percentage is reached, the humidifier switches off automatically. If the room humidity falls below the set level, the humidifier switches back on automatically.
- Timer:** The timer can be set to 1, 2, 4 or 8 hours. If none of the timer icons are lit, the humidifier is in continuous operation mode.
- Night light:** The colour-changing night light can be switched on and off using this button on the remote control. The night light can be switched on and off directly on the unit by holding down the timer button.
- Sleep mode:** In sleep mode, the LED indicator on the device goes out, but the other functions remain active. You can switch this mode on and off by pressing this button on the remote control. Sleep mode can be switched on and off directly on the device by holding down the On/Off button.

Cleaning and maintenance

- ! The tank must be cleaned and refilled with clean water at least every three days.
- ! Always unplug the unit from the mains before cleaning it.
- ! Use only a slightly damp cloth.
- ! Do not immerse the appliance in water.
- ! Do not use any type of chemical detergent.
- ! Warning: repairs to the appliance must only be carried out by a qualified technician.

Environmental protection regulations

- At the end of its life cycle, this product must not be disposed of with normal household waste. Owners of used appliances are required to take them to a collection point for the recycling of electrical appliances. We recommend contacting your local council to find out where your nearest disposal point is. Small appliances, with dimensions not exceeding 25 cm, may be taken to an electronics shop. These obligations are indicated by the symbol on the product, in the user manual or on the packaging.

Warranty

Please keep your receipt, the user instructions and the item number. Any warranty claims or warranty entitlements must be dealt with exclusively through the retailer. All technical data, information and product specifications described in this document have been compiled in good faith and reflect the current status at the time of publication. The information provided by reer is intended to be accurate and reliable. However, reer accepts no liability for any errors contained in this document and reserves the right to modify the product design and specifications without prior notice. Any copying or transmission (even in part) of information from these instructions for use, which are subject to copyright, in any form or by any means, whether graphic, electronic or mechanical, by means of photocopying, audio reproduction or recording on a data retrieval system, requires prior written authorisation from reer.

reer GmbH
Mühlstr. 41
71229 Leonberg
Germany
www.reer.de

Rev. 015022



ES Humidifier

Instructions for use // Item no. 94060

Congratulations on purchasing your new reer humidifier. The humidifier consists of an ultrasonic air humidification module with an integrated night light and a remote control. We are confident that you will enjoy the quality of our product for many years to come. Please take a couple of minutes to read the safety instructions carefully. The reer humidifier can only be used safely if all the points listed here are followed. Keep the instruction manual for future reference.

Technical specifications

Item:	94060 Humidifier
Power:	28W
Operating voltage:	230V
Protection rating:	IPX0
Dimensions (W x H x D):	185 x 290 x 185 mm
Water tank capacity:	5.5 l
Mist output:	max. 300 ml/h
Maximum room size:	30 m ²
Noise level:	≤ 40 dBA (1 m)
Cable length:	125 cm

Contents

1 humidifier, 1 remote control, 1 CR2025 battery incl.

General safety instructions

- ! Before using the device, check that it has no visible damage. If you discover any damage, do not use the device.
- ! Make sure that the voltage at the mains socket matches that of the power supply. Check that the rated voltage matches the voltage indicated on the devices or on the power supply power supply, especially when travelling abroad.
- ! With the exception of the water tank lid, you must not open the appliance, as this may result in electric shocks. If the appliance is not working properly, DO NOT attempt to fix the problem yourself. In that case, contact your dealer.
- ! This product is not a toy! Do not let children play with the appliance.
- ! Keep the appliance and its power cord out of the reach of children under 8 years of age. This appliance is suitable for children aged 8 years and over and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, provided they are supervised or have been instructed in the safe use of the appliance and understand the hazards involved.
- ! Cleaning and maintenance work must not be carried out by children under the age of 8 or without supervision.
- ! Disconnection from the mains supply is only guaranteed when the power supply unit is removed from the mains socket.
- ! The light bulb in the indicator light is not replaceable; once the light bulb has reached the end of its service life, it cannot be replaced.
- ! The humidifier must be emptied, cleaned and dried before storage. The humidifier must be cleaned again before the next use.
- ! There must be no water in the tank when the appliance is not in use. When not in use, disconnect the appliance from the mains.
- ! Warning: Microorganisms present in the water or in the environment where the appliance is to be used or stored may multiply in the water tank and be released into the air. This can therefore pose serious health risks if the water is not changed and the tank is not cleaned properly every 3 days.
- ! Use the appliance solely for its intended purpose.
- ! Use the device exclusively for private use and indoors; it is not intended for commercial use.
- ! Use the device in an upright position only.
- ! Avoid extreme heat and direct sunlight.
- ! Caution: please note that high humidity can encourage the growth of biological organisms in the environment.
- ! Ensure that the air inlets and outlets are not blocked. Therefore, do not place any objects on top of or in front of the appliance.
- ! Please note that the area around the humidifier must not become damp or wet. Reduce the humidifier's output once there is sufficient humidity in the room. Ensure that absorbent items such as carpets, net curtains, curtains or tablecloths do not get wet.
- ! Use a properly connected power socket for the appliance. If the power socket is not connected correctly, the appliance's plug will overheat.

Start-up

Connect the reer humidifier to the mains using the power cable. Open the lid of the water tank and fill it sufficiently with tap water. It is essential to ensure that no water enters the covered air outlet inside the water tank and that the water level does not exceed the fill limit mark. The humidifier will only switch on if there is sufficient water in the water tank.

Description of the symbols on the display



Functions

- ON/OFF:**
Switches the humidifier on and off.
- Humidifier / Mist gauge:**
The humidifier allows you to choose between 4 intensity levels (0/1/2/3). Humidification is deactivated at level 0.
- Air Humidity / Constant Humidity:**
This function can be used to set the desired humidity level in the room in 5% increments (40%–90%). The humidifier switches off automatically once this humidity level is reached. The humidifier switches back on automatically if the humidity level falls below the specified value.
- Timer:**
The timer can be set to 1, 2, 4 or 8 hours. The humidifier runs continuously if no icon is lit on the timer.
- Night light:**
The colour-changing night light can be switched on and off using this button on the remote control. The night light can be switched on and off directly on the unit by holding down the timer button.
- Repeat mode:**
In repeat mode, the device's LED display turns off, but all other functions remain active. You can switch this mode on and off using this button on the remote control. Repeat mode can be switched on and off directly on the device by holding down the power button.

Cleaning and maintenance

- ! The tank must be cleaned and refilled with fresh water at least every 3 days.
- ! Always unplug the power supply from the mains socket before cleaning the appliance.
- ! Use only a damp cloth.
- ! Do not immerse the appliance in water.
- ! Do not use any chemical detergents.
- ! Warning: Only qualified technical personnel may repair the appliance.

Environmental protection guidelines

- At the end of its useful life, this product must not be disposed of with household waste. Owners of old appliances should take them to a collection point for the recycling of electrical equipment. Please contact your local council for details of the relevant disposal point. Small appliances with a maximum side length of less than 25 cm can be handed in at electrical goods retailers. The symbol on the product, in the instructions or on the packaging refers to these obligations.

Warranty

Please keep your proof of purchase, the instruction manual and the item number. Warranty claims or claims under warranty commitments must be processed exclusively through the distributor. All technical data, information and product properties described in this manual have been compiled to the best of our knowledge and belief, and reflect the state of the product at the time of publication. The information provided by reer is correct and reliable. However, reer accepts no liability for any errors in this document and reserves the right to make changes to the product design or specifications without prior notice. Any reproduction or transmission of the information contained in this work, which is protected by copyright law, by any means or method, whether graphic, electronic or mechanical, including photocopying, tape recording or storage in a data retrieval system (including partial reproduction), requires the written authorisation of reer.

reer GmbH
Mühlstr. 41
71229
Leonberg,
Germany
www.reer.de



Rev. 015022

NL Humidifier

User manual // Item no.: 94060

Congratulations on purchasing your new Reer humidifier. The humidifier consists of an ultrasonic atomiser with a built-in night light and a remote control. We are confident that you will enjoy our high-quality product for many years to come. Please take a few minutes to read the safety instructions carefully. The reer humidifier can only be used safely if all the points listed below are observed. Keep the user manual in a safe place so that you can refer to it later if necessary.

Technical specifications

Item:	94060 Humidifier
Power:	28W
Mains voltage:	230V
Protection class:	IPX0
Dimensions (WxHxD):	185 x 290 x 185 mm
Water tank capacity:	5.5 l
Mist output:	max. 300 ml/h
Maximum room size:	30 m²
Noise level:	≤ 40 dBA (1 m)
Cable length:	125 cm

Contents:

1x humidifier, 1x remote control incl. 1x CR2025 battery

General safety instructions

- ! Check the device for visible damage before each use. If the device is damaged, it must not be used.
- ! Make sure that the mains voltage at the socket matches that of the mains adapter. When travelling abroad, in particular, check that the local mains voltage matches the voltage specified on the appliances or mains adapters.
- ! With the exception of the water tank lid, the appliance must not be opened, as this may cause electric shock. If the appliance is not working properly, DO NOT attempt to rectify the problem yourself. In such cases, please contact the dealer.
- ! This product is not a toy. Do not allow children to play with the appliance.
- ! Keep the appliance and the power cord out of the reach of children under 8 years of age.
- ! This appliance is suitable for use by children aged 8 years and above and by persons with reduced physical, sensory or mental capabilities or lack of experience and/or knowledge, provided they are supervised or have been instructed on how to use the appliance safely and understand the hazards involved.
- ! The appliance must not be cleaned or maintained by children under the age of 8 or without supervision.
- ! The device is only guaranteed to be disconnected from the mains when the power adapter has been unplugged from the socket.
- ! The light bulb in the night light is not replaceable and cannot therefore be replaced once it has reached the end of its service life.
- ! The humidifier must be emptied, cleaned and dried before being stored away. The humidifier must be cleaned again before its next use.
- ! Do not leave any water in the tank when the appliance is not in use. Unplug the appliance from the mains when it is not in use.
- ! Warning: Micro-organisms present in the water or in the environment where the appliance is used or stored may grow in the water tank and be blown into the air. If the water is not changed and the tank is not cleaned every 3 days, this may lead to serious health problems.
- ! Use the product only for its intended purpose.
- ! The device is intended exclusively for private indoor use. It is not intended for commercial use.
- ! Always use the appliance in an upright position.
- ! Avoid extreme heat and direct sunlight.
- ! Please note: be aware that high humidity may cause biological organisms to grow in the surrounding area.
- ! Ensure that the air inlet and outlet are not blocked. Therefore, do not place any objects on top of or in front of the appliance.
- ! Please note that the area around the humidifier must not become damp or wet. The humidifier's output will be reduced if moisture is present. Ensure that absorbent materials such as carpets, curtains, net curtains or tablecloths do not become damp.
- ! Ensure the appliance is plugged into a properly fitted socket. If it is not plugged in correctly, the appliance's plug will become hot.

Setting up

Connect the Reer humidifier using the mains cable. Open the lid of the water tank and fill it with sufficient tap water. Take care to ensure that no water enters the covered air outlet of the water tank and that you do not fill it beyond the maximum level mark. The humidifier can only be switched on if there is enough water in the water tank.

Description of display symbols



Functions

- ON/OFF:**
Switches the humidifier on and off.
- Humidifier/mist level:**
You can set the humidifier to 4 settings (0/1/2/3). In setting 0, the humidifier is switched off.
- Humidity/Constant Humidity:**
This function allows you to set the desired humidity level in the room in 5% increments (40%–90%). Once the desired humidity level is reached, the humidifier switches off automatically. If the humidity level falls below the set value, the humidifier switches back on automatically.
- Timer:**
The timer can be set to 1, 2, 4 or 8 hours. If none of the timer icons are lit, the humidifier runs continuously.
- Night light:**
The colour-changing night light can be switched on and off using this button on the remote control. The night light can also be switched on and off directly on the unit itself by holding down the timer button.
- Sleep mode:**
In sleep mode, the LED display on the device is switched off, but the other functions remain active. This mode can be switched on and off using this button on the remote control. Sleep mode can be switched on and off on the device itself by holding down the on/off button.

Cleaning and maintenance

- ! The tank must be cleaned and filled with fresh water at least every 3 days.
- ! Always unplug the appliance from the mains before cleaning it.
- ! Use only a slightly damp cloth.
- ! Do not immerse the appliance in water.
- ! Do not use chemical cleaning agents.
- ! Please note: repairs to the appliance must only be carried out by a qualified technician.

Environmental protection instructions

-  At the end of its useful life, this product must not be disposed of with normal household waste. Owners of end-of-life equipment are required to take it to a collection point for the recycling of electrical equipment. Please contact your local council to find out which waste management service is responsible. Small appliances with a maximum side length of less than 25 cm may be handed in at electronics shops. The symbol on the product, in the user manual or on the packaging.

Warranty

Please retain the proof of purchase, the user manual and the item number. Warranty claims or claims arising from the warranty must be settled exclusively with the retailer. All technical data, information and specifications relating to the product described in this document have been compiled to the best of our knowledge and reflect the status at the time of publication. The information provided by reer must be accurate and reliable. However, reer accepts no liability whatsoever for any errors in this document and reserves the right to make changes to the product design or specifications without prior notice. Reproduction and distribution of the information contained in this copyright-protected work in any form or by any means, whether graphic, electronic or mechanical, by photocopying, recording on tape or storing in a data system (including any part thereof), require the written consent of reer.

reer GmbH
Mühlstr. 41
71229
Leonberg,
Germany
www.reer.de



Rev. 015022

We warmly congratulate you on the purchase of your new reer humidifier. The humidifier consists of the ultrasonic humidifier comes with a built-in sleep indicator light and a remote control. We are confident that you will enjoy the quality of our product for many years to come.

Please take a few minutes to read the safety instructions carefully. Only when all the points listed here are guaranteed, you can use the REER humidifier with confidence. Please keep the user manual in a safe place for future reference.

Technical specifications

Item:	94060 Air Humidifier
Power:	28W
Operating voltage:	230V
Protection rating:	IPX0
Dimensions (W x H x D):	185 x 290 x 185 mm
Water tank capacity:	5.5 l
Mist output:	max. 300 ml/h
Maximum room size: 30 m²	
Noise level:	≤ 40 dBA (1 m)
Cable length:	125 cm

Scope of delivery

1 humidifier, 1 remote control with 1 CR2025 battery

Safety instructions

- ! Before each use, check the device for visible damage. If any defects are found, the device must not be used.
- ! Ensure that the mains voltage at the socket matches the power supply unit's voltage. Check this, particularly during When travelling abroad, check whether the local mains voltage corresponds to the voltage specified on the devices or power adapters.
- ! The appliance must not be opened, with the exception of the water tank lid, as this may result in electric shock. If the appliance malfunctions, DO NOT attempt to repair it yourself. In such cases, please contact your retailer.
- ! This product is not a toy. Do not allow children to play with this appliance.
- ! Keep the appliance and its power cable out of the reach of children under 8 years of age.
- ! This appliance is suitable for use by children aged 8 years and above, as well as by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, provided they are supervised or have been instructed on how to use the appliance safely and understand the risks involved.
- ! Cleaning and maintenance by the user must not be carried out by children under the age of 8 or without supervision.
- ! The only way to disconnect the appliance from the mains is to remove the power plug from the socket.
- ! The light source in the nap indicator light is not replaceable; once the light source has reached the end of its service life, it cannot be replaced.
- ! Before storing the humidifier, it must be emptied, cleaned and dried. The humidifier must be cleaned again before its next use.
- ! Water must not be left in the tank when the appliance is not in use. When the appliance is not in use, it must be disconnected from the mains.
- ! Warning: Microorganisms that may be present in the water or in the environment where the device is used or stored may grow in the water tank and be blown into the air. This can lead to serious health risks if the water is not changed and the tank is not cleaned properly every 3 days.
- ! Please use this product only for its intended purpose.
- ! This device is intended solely for private indoor use and must not be used for industrial applications.
- ! Use the device in an upright position only.
- ! Avoid extreme heat and direct sunlight.
- ! Caution: It should be noted that high air humidity may encourage the growth of biological organisms in the surrounding environment.
- ! Ensure that the air inlet and outlet are not blocked. Therefore, do not place any objects on top of or in front of the unit.
- ! Please note that the area around the humidifier must not be damp or wet. If dampness is present, reduce the humidifier's output. Ensure that non-absorbent items such as carpets, curtains, net curtains or tablecloths do not become damp.
- ! Please ensure the appliance is plugged into a properly connected electrical socket. If it is not properly connected, the appliance's plug will become hot.

Start-up

Connect the reer humidifier using the power cable. Open the lid of the water tank and pour in a sufficient amount of tap water. Ensure that no water enters the covered air outlet inside the water tank and that the water level does not exceed the mark maximum fill level. The humidifier can only be switched on if there is sufficient water in the water tank.

Description of display symbols



Function

- ON/OFF:**
Switches the humidifier on and off.
- Humidifier / mist generator:**
You can choose between 4 intensity levels (0/1/2/3) for the humidifier. At level 0, the humidifier is switched off.
- Air humidity / constant humidity:**
Using this function, you can set the required humidity in the room in increments of 5% (40%–90%). As soon as this humidity level is reached, the humidifier switches off automatically. If the humidity falls below the set value, the humidifier switches on again automatically.
- Timer:**
The timer can be set to 1, 2, 4 or 8 hours. If none of the timer icons are lit, the humidifier is operating in continuous mode.
- Night light:**
The colour-changing night light can be switched on and off using this button on the remote control. The night light can also be switched on and off directly on the device by pressing and holding the clock control button.
- Sleep mode:**
In sleep mode, the LED display on the device is switched off, but the other functions remain active. You can activate this mode using this button on the remote control and switch it off. You can activate and deactivate sleep mode directly on the device by pressing and holding the On/Off button.

Cleaning and maintenance

- ! The tank must be cleaned and refilled with fresh water at least every 3 days.
- ! Always unplug the power supply from the mains socket before cleaning the appliance.
- ! Use only a slightly damp cloth.
- ! Do not immerse the device in water.
- ! Do not use any chemical cleaning agents.
- ! Note: Repairs to the device may only be carried out by qualified personnel.

Environmental guidelines

- ! Once the product has reached the end of its useful life, it must not be disposed of with ordinary household waste. Owners of end-of-life equipment are required to take it to a collection point for electrical appliances intended for recycling. Please enquire at your local council office about the appropriate waste collection point. Small appliances with a maximum edge length of less than 25 cm may alternatively be returned to an electrical goods retailer. Appropriate
- A symbol on the product, in the user manual or on the packaging indicates these obligations.

Warranty

Please retain your proof of purchase, user manual and item number. Warranty claims or claims under a warranty undertaking may only be made against the seller. All technical data, information and product features described in this document have been compiled to the best of our knowledge and in accordance with the state of the art at the time of publication. Information prepared provided by Reer are accurate and reliable. However, the company accepts no liability for any errors contained in this document and reserves the right to make unannounced changes to the product design in relation to the specifications. The reproduction and distribution of the information contained in this copyright-protected document in any form or by any means, whether graphic, electronic or mechanical, including photocopying, recording on tape or storing in a data retrieval system (including in part), requires the prior written consent of reer.

reer GmbH
Mühlstr. 41
71229
Leonberg,
Germany
www.reer.de



Rev. 015022

CZ Humidifier

User manual // Product no.: 94060

Congratulations on purchasing your new reer humidifier. The humidifier comes with an ultrasonic humidifier module featuring a built-in night light and a remote control. We are confident that you will enjoy the quality of our product for many years to come. Please take a few minutes to carefully read through the safety instructions. The reer humidifier can only be used safely if all the points listed here are observed. Please keep the user manual in a safe place for future reference.

Technical data

Product:	94060 Humidifier
Power:	28W
Operating voltage:	230V
Protection rating:	IPX0
Dimensions (W×H×D):	185 x 290 x 185 mm
Water tank capacity:	5.5 l
Humidification capacity:	max. 300 ml/h
Maximum room size:	30 m²
Noise level:	≤ 40 dBA (1 m)
Cable length:	125 cm

Contents:

1x humidifier, 1x remote control incl. 1x CR2025 battery

Safety instructions

- ! Before using the device, check that it is not visibly damaged. If the device is damaged, it must not be used.
- ! Ensure that the operating voltage of the socket corresponds to the operating voltage of the mains adapter. When travelling abroad in particular, check that the local mains voltage matches the voltage specified on the devices or mains adapters.
- ! With the exception of the water tank cover, the appliance must not be opened, as this could result in electric shock. If the appliance is not working properly, DO NOT ATTEMPT to resolve the problem yourself. In such cases, contact your retailer.
- ! This product is not a toy. Children must not play with the device.
- ! Keep the device and its power cable out of the reach of children under 8 years of age.
- ! This appliance is suitable for use by children aged 8 years and above and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, provided they are supervised or have been instructed on how to use the appliance safely and understand the potential hazards involved.
- ! Cleaning and user maintenance should not be carried out by children under 8 years of age or without supervision.
- ! Disconnection from the mains can only be guaranteed if the power adapter cable is unplugged from the socket.
- ! The night light bulb cannot be replaced. Once the bulb has reached the end of its service life, it cannot be replaced.
- ! The humidifier must be emptied, cleaned and dried before storage. The humidifier must be cleaned again before next use.
- ! When the appliance is not in use, there must be no water left in the tank. When the appliance is not in use, unplug it from the mains.
- ! Warning: Microorganisms that may be present in the water or in the environment where the device is used or stored may grow in the water tank and be released into the air. It is therefore essential to change the water in the tank regularly and to clean the tank thoroughly every 3 days. Failure to do so may pose serious health risks.
- ! Use the product only for its intended purpose.
- ! Use the device for private use indoors only – it is not intended for commercial use.
- ! Use the device in an upright position only.
- ! Avoid extreme heat and direct sunlight.
- ! Please note: It should be emphasised that high air humidity may encourage the growth of biological organisms in the surrounding area.
- ! Ensure that the air inlets and outlets are not blocked. Therefore, do not place any objects on or in front of the device.
- ! Remember that the area around the humidifier must not be damp or wet. If dampness occurs, reduce the steam output from the humidifier. Ensure that absorbent materials, such as floor coverings, curtains, net curtains or tablecloths, do not become damp.
- ! Use a properly connected electrical socket for this appliance. If the socket is not connected correctly, the appliance's plug may become hot.

Commissioning

Connect the reer humidifier to the mains using the power cable. Open the water tank lid and pour in plenty of tap water. It is very important to ensure that no water enters the covered air outlet inside the water tank and that the water level in the tank does not exceed the maximum fill line. The humidifier can only be switched on if there is sufficient water in the water tank.

Description of symbols on the display



Functions

- ON/OFF:**
Used to switch the humidifier on and off.
- Humidifier / Fog meter:**
You can switch between 4 humidity levels (0/1/2/3) on the humidifier. At level 0, the humidifier is switched off.
- Humidity / Constant Humidity:**
This function allows you to set the desired humidity level in the room in 5% increments (40–90%). Once the humidity reaches this level, the humidifier switches off automatically. If the humidity falls below the set level, the humidifier switches on again automatically.
- Timer:**
The timer can be set to 1, 2, 4 or 8 hours. If none of the timer symbols are lit, the humidifier is operating continuously.
- Night light:**
The colour-changing night light can be switched on and off using this button on the remote control. On the unit itself, the night light can be switched on and off by pressing and holding the timer button.
- Sleep mode:**
In sleep mode, the LED display on the device is switched off, but the other functions remain active. You can switch this mode on and off using this button on the remote control. On the device itself, you can activate and deactivate sleep mode by pressing and holding the On/Off button.

Cleaning and maintenance

- ! The tank must be cleaned and refilled with fresh water at least every 3 days.
- ! Always unplug the appliance from the mains socket before cleaning.
- ! Use only a slightly damp cloth.
- ! Do not immerse the device in water.
- ! Do not use any chemical cleaning agents.
- ! Warning: Repairs to the device must only be carried out by qualified personnel.

Environmental protection notice

-  This product must not be disposed of with normal household waste at the end of its useful life. Owners of old appliances are required to take them to a collection point for the recycling of electrical appliances. Please contact your local council to find out where to dispose of the waste. Small appliances with a maximum edge length of less than 25 cm may, where applicable, be handed in at an electronics shop. A symbol on the product, in the user manual or on the packaging draws attention to these obligations.

Warranty

Please keep your proof of purchase, the user manual and the product number. Warranty claims or claims under the guarantee must be dealt with exclusively by the retailer. All technical data, information and product features described in this manual correspond to the state of our knowledge at the time of publication. The information provided by reer is intended to be accurate and reliable. Nevertheless, the company accepts no liability for any errors contained in this document and reserves the right to change the product design or its specifications without prior notice. The reproduction and distribution of information from this document, which is protected by copyright law, in any form or by any means, whether graphic, electronic or mechanical, including the making of photocopies, recordings or storage in databases (even in the form of extracts), is subject to the prior written consent of reer.

reer GmbH
Mühlstr. 41
71229
Leonberg,
Germany
www.reer.de



Rev. 015022