



Deep Tissue Muscle Massage Gun



Appearance



Product Introduction

30 Levels Frequency Conversion Adjustable

Digital display



Small round head
Suitable for internal deep tissue
Acupoint massage, etc.



Flat head
Suitable for all muscle parts
Relax and shape



Cylindrical head
Suitable for impacting deep tissue
Such as Meridian, Palm, sole, etc.




Ball head
Suitable for massaging arms, waist and back
Big hips, thighs, shank, etc.
Muscle Group



Shovel head
Suitable for abdominal muscles
line carving and relaxation



U-shaped head
Suitable for massaging neck and neck
Spine and Achilles tendon



Muscle fascia massage gun is a portable and rechargeable vibration massage device with high torque, long battery life and Multi-position adjustment features. It can effectively alleviate the soreness caused by lactic acid accumulation after strenuous exercise, and slow down the discomfort of the muscles of all the people who have been sitting for a long time.

Product Specifications

Parameter

Model: JM-001

Product Name: Deep Tissue Muscle Massage Gun

Net weight : 950g

Gross weight: 1600g

Rated voltage: ☐DC12V ☐DC24V

Rated frequency: 20-58Hz

Battery capacity: 2400mAh

Features

Quiet,high frequency,high torque,light weight

Function introduction

Improve muscle bruises, sprains, strains and pains

Helps the edema fluid flow in the swollen area

Relaxation and thickening of connective tissue and fascia

Reduce the accumulation of lactic acid in muscles


Increase joint mobility

Eliminate muscle fatigue

Packing list

Massage gun host *1 • massage head *6 • adapter *1
manual *1 • Original storage box*1

Instructions For Use



1. Open the device at the bottom of handle
2. Press the button to power on and start running.
3. The keys " + " " - " can adjust for the levels from 1-30 .
4. When the battery charge is less than 20%, the bottom line of the machine is shown in red; when the battery is less than 10%, If the "E1" is displayed in the battery display window, it will not work and you need to charge it immediately.
5. Power display changes from 00 to 99 in successively when charging, and reaching to 99 means power charging full. At the same time, When the battery is fully charged, the light line at the bottom of the machine changes from red to green.
6. This device has a timing function and automatically stops running after 10 minutes of operation.
7. The device will start the automatic protection function and the machine stops running when you strongly pressed the massage head stop the motor . The frequency will displayed as "E4" , it can be used normally after switching on button.

Maintenance

- Do not immerse in water, keep away from liquids or heat sources, and do not allow water to enter the vents of the "product".The vents are free of dust and debris.
- Do not drop or improperly use the "product", do not remove the screws or attempt to disassemble, do not change or modify the "product" in any method.
- Do not operate continuously for more than 1 hour, and let the device rest for 30 minutes before re-use.
- Charge only with the local charger and carefully check the device and battery before each use.
- In order to protect and extend the battery life, Please turn off the Bottom Switch of the product after use.
- Unplug the charger from the device after charging or before use.
- Do not operate or charge the product unattended.

Precautions

To reduce the risk of electric shock, fire and personal injury, this product must be used as follows:

1. For adults only, it can be used only on dry parts of the body and clean skin. It can't be used across the clothes. Gently press and move on the skin for about 60 seconds.
2. Use the "product" only in the soft tissues of the body without causing pain or discomfort; do not use on any hard parts such as bones on the head or the body.
3. Use only massage heads that produce the best results
4. Whether it is controlled by underground pressure or pressure, it may cause bruises; often check the massage area, you should stop using immediately once it appears with signs of pain or discomfort.
5. Avoid contact with the massage head and the body at the finger, hair or other parts of the body. Beware of pinching.
6. This product is prohibited under the following conditions
 - 1) Blood stasis
 - 2) Tumor site
 - 3) Heart disease, with a pacemaker or defibrillator
 - 4) If you have experienced joint surgery within 90 days, the product should not be used on the body within 3 inches of the surgical position.
 - 5) Sensitive areas: head, face, cervical vertebrae, spine vertebral body
 - 6) Positions close to the bone with less muscle coverage: the humerus, the back of the foot, the back of the hand

Thank you for purchasing our products.

In order to use this product safely and satisfactorily, please read the instructions and safety regulations carefully before use.

Disclaimer

Please read the instruction manual carefully before using this equipment, use this equipment correctly in accordance with the instructions, our company will not be liable for any damage or loss to the customer caused by incorrect use or this equipment as explained. Do not use this device without the approval of your doctor if: pregnancy, diabetes and complications, neuropathy or retinal damage, pacemaker wear, had surgery recently, migraines, disc protrusion or spinal inflammation recently, IUDs have been had or have health problems. You must consult your doctor first and use it with your doctor's permission. We are studying the effects of the device on specific medical conditions, this may cause the above taboo symptoms to be not detailed enough if you are unwell please stop using it, follow the advice of a physician or physiotherapist.

Warranty Introductions

We provide warranty for battery, motor, controller of one year, other wearing parts warranty of three months.

Except while:

1. Damage to this equipment caused by man-made incorrect operation or transport.
2. Unauthorized removal and repair of this equipment.
3. Did not follow the instruction manual.
4. Overloaded use of this product design parameter.
5. Damage due to the customer's unusually poor storage or maintenance environment.
6. Failure to provide proof of purchase date.