


中英说明书 7折页8面 单黑 折好后: 58*60mm 风琴折

材质：128克铜板


印刷的时候去掉成品线

使用说明书



▶ 入门指南

耳机概述



• 请确认您的蓝牙耳机配有下列物品：USB充电线、蓝牙耳机、耳套和使用说明书

蓝牙版本5.0	待机时长 约 250 小时	传输距离 10M	充电电压 DC 5V
通话时间 约 16 小时	电池容量 170mAh	充电时间 约 2 小时	

▶ 启动蓝牙耳机

- 开机：长按多功能键约2秒，直到蓝灯闪3次
- 关机：长按多功能键约3秒，直到红灯闪3次熄灭
- 接听/结束通话：单击多功能键
- 听歌/暂停：单击多功能键
- 拒绝来电：长按多功能键约2秒
- 重拨：快速双击多功能键
- 语音拨号：长按多功能键约2秒开启语音拨号
- 上一曲：长按音量键+约2秒
- 下一曲：长按音量键-约2秒
- 提示音切换：快速三连击多功能键
- 充电时：红灯常亮
- 充满时：长亮蓝灯
- 低电量语音提示：电量不足

▶ 耳机配对



1. 长按住多功能键约2秒，这时指示灯红蓝互闪，耳机进入配对状态。

2. 打开手机上的蓝牙，搜索到对应型号的蓝牙耳机，点击该耳机自动完成配对连接。

▶ 断开耳机与手机的连接

要断开耳机与手机的链接（例如：将手机连接至其他蓝牙设备）请采用以下任一方式：

☆ 关闭耳机

☆ 使用手机的蓝牙功能断开耳机与手机的连接

☆ 将耳机移至距离手机10M（约30英尺）以外的距离

▶ 连接二部手机

一拖二功能，先配对连接第一台手机，然后关闭耳机重新进入配对，用第二台手机连接配对完成后，在第一台手机蓝牙设置里面点击该耳机，则耳机将同时连接两台手机。

▶ 耳机充电

耳机内置可再充电电池。首次使用耳机前,我们建议先将耳机完全充电。充电时，指示灯亮红色，电池充满时红色指示灯将转化为蓝色长亮状态。

△ 注意：请使用原厂专配充电线，充电电压不能高于5V!

▶ 耳机佩戴

根据佩戴耳机的具体位置，对耳套相应的略作调整。

▶ 疑难排除

- 听到【咔咔】的声响？
因蓝牙的协议距离是空旷地段，无障碍情况下可以达到10M，其中人体对蓝牙耳机来讲也是一种最大的干扰障碍，我们建议您 把耳机戴在手机的同一侧，以达至最佳的使用效果。
- 耳机没有声音？
1.请确保耳机已启动并完全充电。
- 手机与耳机连接不上？
1.请确保耳机与手机配接。
2.请确保手机的蓝牙装置已被启用。
3.请确保耳机位于手机10米范围之内，而当中并没有任何障碍物，例如墙壁或其它电子器材等。
- 如以上步骤未能解决问题,请尝试以下操作：
A、重新把耳机充电。
B、重启手机。
C、启动手机蓝牙功能并且删除以往所在配对历史记录！
D、将蓝牙耳机重新与手机进行配接！

△ 注意事项：

(1) 切勿把本耳机放在车内安全气囊的位置上，因为当安全气囊弹出时，可能会引致严重的伤害。
(2) 切勿让儿童玩耍本耳机，细小的零件可能令儿童有窒息的危险。
(3) 医院、爆破地点或潜在爆炸环境的地方，可能会要求用户关掉电子器材及无线电装置。当进入特定范围内请留意有关指示。
(4) 登机前请先把耳机关掉，在飞机内不可使用本耳机。
(5) 为更好的保护您的听力，请勿把音量调得太大。
(6) 切勿试图对本耳机作出任何修改或拆卸。
(7) 切勿在潮湿或雨中使用本产品。
(8) 当处于充电状态时，请勿清洁本耳机。应先把耳机及充电器分开，再进行清理。

△ 注意


如果电池更换不当会有爆炸危险
只能用同样类型或等效类型的电池来更换
电池（电池包或组合电池）不得暴露在诸如日照、火烤或类似过热环境中的警告。

产品质量保修卡：

产品型号	
商品产地	
用户姓名	
销售地点	
销售日期	
销售商名称	
销售商联系电话	
维修记录	


•在 接 受 服 务 时 必 须 提 供 此 保 修 卡 ， 请 妥 善 保 管 ！

User's Guide



▶ Getting Started Guide

Headset overview



• Make sure your Bluetooth headset is equipped with the following items: USB charging cable, Bluetooth headset, earmuffs and instruction manual

Bluetooth version: 5.0	Standby time: about 250 hours	Transmission distance:10M	Charging voltage:DC 5V
Talk time: about 16 hours	Battery capacity: 170mAh	Charging time: about 2 hours	

▶ Open the Bluetooth headset

- Power on: press and hold the multifunction buton for about 2 seconds until the blue light flashes 3 times;
- Power off: press and hold the multifunction buton for about 3 seconds until the red light flashes 3 times;
- Answer/end call: click on the multifunction key;
- Song/Pause: click on the multifunction key;
- Reject the call: long press multifunction buton for about 2 seconds;
- Redial: quickly double-click the multifunction key;
- Voice dialing: long press multi-function buton for about 2 seconds to start voice dialing;
- Previous song: long press the volume key + about 2 seconds;
- Next song: long press the volume buton - about 2 seconds;
- Prompt tone switch: fast triple tap multi-function key
- Charging: Flash red light long time
- When full: long blue light
- Low battery voice alert: low battery

▶ Headset pairing



1. Press and hold the multifunction buton for about 2 seconds, at this time, the indicator lights flash red and blue,the headset goes into pairing.

2. Turn on your phone bluetooth function,search for the model name of headphones, then click it will automallly connect.

▶ Disconnect the headset from the phone:

To disconnect the headset from the phone (For example, connect your phone to another Bluetooth device), use one of the following:

Turn off headphones:

☆ Use the phone's Bluetooth function to disconnect the headset from the phone

☆ Move the headset to a distance of 10M (about 30 feet) away from the phone

▶ Connect two phones

A drag two functions, the first pair of connected to the first mobile phone, and then turn off the headset new entry match, with second mobile phone connection pairing finished in the first one phone Bluetooth settings inside the click on the headset, the headset will also connect two mobile phone.

▶ Headset charging

Headset built-in rechargeable battery, before using the headset for the first time, we recommend first the headset is fully charged. when charging, the indicator light is red, the battery is full when the red the color indicator will be converted to blue long.

△ Note: Please use the original charge with the charge, the charging voltage can not be higher than 5V!

▶ Headphones to wear

- According to the specific location of wearing headphones, the corresponding slightly adjustable ear sets.

▶ Troubleshoot

Heard the sound of [Kaka]

- Because the Bluetooth agreement is open from the open location, accessible circumstances can reach to 10M, in which the human body is also the largest in terms of Bluetooth headset dry we recommend that you put your headphones on the same side of your phone to achieve the best results.

• Does the machine have no sound?

1. Make sure the headset is activated and fully charged.

• Phone and headset is not connected?

1. Make sure the headset is matched to the phone.
2. Make sure your phone's Bluetooth device is enabled.
3. Make sure the headset is within 10 meters of the phone and not any obstructions, such as walls or other electronic equipment.

• If the above steps do not resolve the issue, try the following:
A、re-charge the headset.
B、restart the phone.
C、start the phone Bluetooth and delete the previous pairing history!
D、the Bluetooth headset to re-match with the phone!

△ Precautions:

(1) Do not place this headset in the position of the airbag inside the vehicle when the airbag pops up, it may cause serious injury.
(2) Do not let children play the headphones, small parts may make children have the risk of suffocation.
(3) Hospitals, blasting sites or places where potentially explosive atmospheres may be ask the user to turn off the electronic equipment and radio, when you enter a specific area please pay attention to the instructions.
(4) Before boarding, please turn off the headset, to the aircraft can not use the headset.
(5) To better protect your hearing, do not adjust the volume too loud.
(6) Do not attempt to make any modifications or disassembly of this headset.
(7) Do not use this product in wet or rain.
(8) Do not clean the headphones while in the charging state. should first headphones and the charger separately, and then clean up.

△ Be careful!l

The battery is not replaced properly, there will be explosion danger. Can only be replaced with the same or equivalent type of battery Batteries (battery packs or combination batteries) should not be exposed to warnings such as sunlight, fire or similar overheating.

Product quality warranty card:

Product Model	
Origin of Product	
User Phone	
Sale Location	
Sales Date	
Vendor Name	
Vendor Contact Phone	
Maintenance Records	

•Please provide this warranty card when accepting the service, please keep it safe!