



材质：80g书纸，
尺寸：60x170mm
印刷：单黑，正反印刷，折页

Bracket instruction:


Step 1:
Press the triangle button at the bottom of the product to turn into the tripod mode.



Step 2:
Pull the telescopic rod out to a proper length. The length of the stick is adjustable.



Note:
Tripod legs will be automatically released and closed when stretch and retract the telescopic rod. Please do not put your hands directly on the surface of tripod legs to avoid being pinched.




PORTABLE
TRIPOD
SELFIE STICK

OTH-AB403
Rechargeable Version

Bluetooth Connection:


Fix the mobile phone to the phone holder and press the shutter button of the remote controller for 2 seconds. The green light flashes, indicating Bluetooth pairing mode. Then turn on your phone's Bluetooth, search and connect to "SEAJIC". Green light will last long time when paired successfully, press the shutter button of the remote controller to take pictures.



Remove Remote Controller:


The remote controller of this product is detachable. Please stretch out the telescopic rod a little and then push up the remote controller to use it independently.

The Bluetooth remote controller is rechargeable. Please remove the remote controller to charge when its battery is low after long-time usage.




Bracket Rotation:

First:
Rotate the phone holder upward from the back of the product until it forms a 7-shape with the handle part.



Second:
Hold the handle part with one hand and horizontally rotate the phone holder 180 degrees with the other hand.



Finally:
Stretch the telescopic rod. Unfold the silicone clip of the phone holder and fix your phone.

