
390mm

125mm


正面

A35
使用说明书

欢迎使用A35手机摄影支架！




产品操作步骤




松开扭头可上下调节角度，完成角度调节后锁紧扭头。


拉开手机夹，将手机放入并夹紧。



先从底部向外拉开三角架。




向外打开三脚架。



按住滑套并将其向下拉至末端完全展开，收回时按住滑套收起支架。




1/4相机螺丝通用摄影配件。



拉伸横杆至所需的长度。



用手指将遥控器从手柄下方取出。



俯拍时先松开扭头将手机调至俯拍所需角度后再拧紧扭头锁定。



抖音遥控器可进行视频滑动、点赞可远程拍摄拍照。

蓝牙遥控器操作说明





1.拨动遥控器背面开关（ON开启/OFF关闭），遥控器指示灯自动闪烁。
2.打开手机"设置"-"蓝牙"开启蓝牙，搜索"ADYSS-A1"点击设备名称配对，显示"已连接后"，指示灯停止闪烁，即连接成功（遥控器开启状态）。
3.**方向键：**看抖音上下键切换视频，左右键左滑动右滑动。
4.**点赞键：**看抖音（双击点赞）或其他视频软件时单击暂停/继续播放，进入拍摄界面单击自动对焦。
5.**拍摄键1：**支持手机相机/美颜相机等各种拍照软件（连上蓝牙即用）。
6.**拍摄键2：**支持抖音/快手/微信等所有软件拍视频（少部分机型需设置）。

特别说明：（苹果IOS系统设置与拍摄键2无效时设置方法如下）
1.苹果IOS13.4以上设置方法：**a.**遥控链接上手机蓝牙 **b.**屏幕自动旋转锁定 **c.**打开设置-辅助功能-触控-辅助触控-打开 **d.**IOS15以上系统首次使用需校准，找到辅助触控的圆环灵敏度将圆点移到左边后再移回默认位置即可。
2.拍摄键2无效时调整快门键位置方法：**a.**进入软件拍摄界面 **b.**长按拍摄键2不松手 **c.**同时短按方向键移动"指针/圆点"至拍摄软件快门圆圈范围内。

产品参数

产品型号：A35

最大承重能力：500g	工作电压：3.0V
主要材料：不锈钢&ABS塑料	工作温度：-20~60C°
支持系统：Android，IOS，鸿蒙	充电电压：DC 5V
手机夹最大拉伸距离：86mm	遥控器电池容量：240mA
折叠尺寸：45*59*283mm(折叠)	
遥控器待机时间：360天	

支持手机型号：

苹果系列机型（IOS 5.0以上系统）

安卓系列机型（Android 4.2 .2以上系统）
请按时更新手机系统，避免版本过低无法兼容使用

⚠ 注意事项

- 请小心收纳，避免夹手
- 使用前请确认使用地域和设施限制的场所，禁止违法公共秩序的行为
- 请勿将产品置于高处及不平坦台面、地面，以及防跌落损伤
- 请勿使用超出产品负荷电源，导致产品发热及电路板烧坏
- 请勿自行拆开、改造本产品
- 请勿撞击、投掷本产品，容易引起内部故障
- 请勿将本产品置入低温、潮湿地方
- 请勿将本产品丢入火中、近离火源
- 警告：本产品不适合3岁及以下儿童单独操作使用

保修卡

产品型号：	购买地址：
购买日期：	订单号码：
客户姓名：	保修内容：
联系地址：	

一年有限保修摘要


我司保证所附带的硬件产品，从原先零售购入的日期一年内在材料和工艺方面无瑕疵，均可受理售后问题。我司对正常使用磨损不做担保，对于事故或滥用造成的损坏也不做担保。若要获取服务可访问我司拥有的零售店或我司授权服务商，即可为你的产品酌情进行修理、更换你享有的保修权益是附加在本地消费者法律所提供的权利以外的。当您根据本保修政策提出索赔时，可能需要提供购买证明的详细信息。

MADE IN CHINA


反面

A35
INSTRUCTIONS

Welcome to use A35 mobile phone photography support!



Product operation steps




Loosen the twist head to adjust the angle up and down. Lock the twist head after completing the angle adjustment.


pen the mobile phone clip, put the mobile phone in and clamp it.




First pull the tripod outward from the bottom.




Open the tripod outward.



Press and hold the sliding sleeve and pull it down until the end is fully deployed. When retracting, press and hold the sliding sleeve to retract the bracket.




1 / 4 camera screw general photography accessories.



Pull the telescopic arm to the required length.



Take out the remote control from under the handle with your fingers.





When shooting down, loosen the twist to adjust the mobile phone to the angle required for shooting down, and then tighten the twist lock.



Tiktok remote controller can slide video, like and take photos remotely.

Operating instructions of Bluetooth remote controller





1.Turn the back switch of the remote controller (ON / OFF), and the indicator light of the remote controller will flash automatically.
2.Turn on "Settings" - "Bluetooth" of the mobile phone, turn on Bluetooth, search for "ADYSS-A1", click the device name pairing, display "connected", the indicator stops flashing, that is, the connection is successful (the remote controller is turned on).
3. **Direction keys:** Watch the video of switching between the up and down keys of Tiktok. The left and right keys slide left and right.
4. **Like button:** Click pause / continue to play when watching Tiktok (double click like) or other video software, enter the shooting interface and click auto focus.
5. **Photo button1:** Support mobile phone camera / Beauty camera and other photographing software (connected to Bluetooth for instant use).
6. **Photo button2:** Support all software such as Tiktok / Kwai / wechat to shoot videos (a few models need to be set).

Special note: (when Apple IOS system setting and shooting key 2 are invalid, the setting method is as follows)
1. Apple IOS 13.4 above setting method: **A.** Mobile phone Bluetooth on the remote control link **B.** the screen automatically rotates and locks **C.** turn on settings - auxiliary functions - touch - auxiliary touch - turn on **D.** the above systems need to be calibrated for the first time. Find the tracking sensitivity of the auxiliary touch and move the dot to the left and then back to the default position.
2. Method of adjusting shutter key position when shooting key 2 is invalid: **A.** Enter the software photographing interface **B.** press the photographing key 2 for a long time without letting go **C.** at the same time, press the direction key for a short time to move the "pointer / dot" to the range of the photographing software shutter circle.

Product parameters

Product model：A35

Maximum bearing capacity：500g	Working voltage：3.0V
Main material：Stainless steel& ABS plastic	Operating temperature：-20°~60°
Support system：Android,IOS,Hongmeng	Charging voltage：DC 5V
Maximum stretching distance：86mm	Remote control battery capacity：240mA
Folding size：45*59*283mm	
Standby time of fill light：360day	

Mobile phone models supported：

Apple series models (IOS 5.0 or above)

Android series models (Android 4.2.2 or above)
Please update the mobile phone system on time to avoid incompatible use of too low version.

⚠ Matters needing attention

- Please store it carefully to avoid pinching your hands.
- Before use, please confirm the places with geographical and facility restrictions, and prohibit acts against public order.
- Do not place the product on high places, uneven countertops and floors to prevent falling damage.
- Do not use the power supply exceeding the load of the product, which will cause the product to heat up and the circuit board to burn out.
- Do not disassemble or modify this product by yourself.
- Do not hit or throw this product, which may cause internal failure.
- Do not put the product in a low temperature and humid place.
- Do not throw the product into the fire and keep away from the fire source.
- Warning: This product is not suitable for children under 3 years old to operate alone.

WARRANTY CARD

Product model：	Place of purchase：
Date of purchase：	Order number：
Customer name：	Warranty content：
Contact address：	

One year limited warranty summary

Our company guarantees that the attached hardware products are free from defects in materials and workmanship within one year from the date of original retail purchase, and can accept after-sales problems. Our company does not guarantee normal wear and tear, nor does it guarantee damage caused by accident or abuse. To obtain the service, you can visit the retail store owned by Our company or the authorized service provider of Our company to repair and replace your products at your discretion. Your warranty rights are in addition to the rights provided by local consumer law. When you file a claim under this warranty policy, you may need to provide details of the proof of purchase.

MADE IN CHINA

	项目名称	A35中英文说明书-中性-R2	制图人	XIANG
	物料编码		审核人	
	比　　例	1:1	日　　期	2022-11-01
			颜　　色	白色折页

尺寸:390*125mm
材质:128g双铜 折页
正面中文 背面英文