

74mm

110mm

FINGERPRINT LOCK

YOUR FINGER IS THE KEY



Fingerprint



60mAh



0.5s Unlock



Security

Operating Instructions / 操作说明

How to Collect The First Administrator's Fingerprint
首次（管理员）指纹录入说明

1. Press the fingerprint sensor. 1. 长按指纹识别器。
2. Left your finger when blue light flashing. 2. 蓝灯亮，松开手指。
3. Start collecting fingerprint. Record 5x with the finger. 3. 开始采集指纹，同一手指采集5次，不同角度，不同方向采集。
4. Successfully collecting fingerprint when blue light flashes. Failed to collect fingerprint when red light flashes. 4. 蓝灯亮，采集成功。红灯亮，采集失败。
5. There is a green light flashes continuously when finish collecting. 5. 累计5次成功采集，绿灯亮，管理员指纹采集成功。

How to Collecting The 2nd to 20th Fingerprints
第二个到第十个指纹录入说明

1. The admin press the fingerprint sensor. 1. 管理员长按指纹识别器。
2. Left admin's finger when blue light flashing. 2. 蓝灯亮，松开手指。
3. Start collecting fingerprint. Record 5x with the finger. 3. 开始采集指纹，第二枚手指采集5次，不同角度，不同方向采集。
4. Successfully collecting fingerprint when blue light flashes. Failed to collect fingerprint when red light flashes. 4. 蓝灯亮，采集成功。红灯亮，采集失败。
5. There is a green light flashes continuously when finish collecting. 5. 累计5次成功采集，绿灯亮，指纹采集成功。

Remarks:
备注:
1. The first and second fingerprints are the admins by default.
1. 默认第一、第二枚指纹为管理员指纹。
2. One of the admins fingerprint will be need to authorize when adding fingerprints.
2. 采集第二到第十枚指纹需要管理员指纹授权。

How to Delete Fingerprints
删除指纹说明

1. The admin press the fingerprint sensor. 1. 管理员长按指纹识别器。
2. Left admin's finger when red light flashing. 2. 红灯亮，松开手指。
3. Press again, the green light will be on, all the fingerprints deleted successfully. 3. 管理员指纹录入，绿灯亮指纹删除成功。

Remarks:
备注:
All fingerprints is deleted at the one time.
只有管理员才能删除指纹，并且是一次性删除全部指纹。

温馨提示：关锁时，请稍微用力将锁梁压到底。
Tips: Please press the lock beam as hard as possible when lock.