

R89 WiFi Camera User Manual




Please charge the camera for 5 hours before use
Please use 2A or 1A adapter to charge it

Warm Tips:

1. Please charge the camera for 5 hours before use. It may be in low power after long-time transportation.
2. The camera ONLY supports 2.4G Wi-Fi router.
3. Please keep the camera close to the phone and router within 5 meters for strong signal the first time you set it up, and better avoid obstacles like walls and doors. Weak router network will influence video transmission fluency and cause frame delay.
4. Please insert a Micro SD card(MAX 128G, NOT included) to save recordings so that you can playback them on the computer. Format the card for the first time use. Please turn off the camera every time when you insert or remove the card, or the recording files will be damaged or fail to be saved.
5. Please set Network WiFi settings in the APP System settings to keep your camera directly connected with the router for remote viewing, or the camera would be offline and disconnect when you are away from the cam.

I. Product Structure



Button Description:

- | | | |
|---|------------------------|-----------|
| 1. 4K Len | 2. Infrared Night LEDs | 3. ON/OFF |
| 4. Video/Reset(Long press for 6 seconds) | | |
| 5. Photo/Turn off Indicator LEDs(Long press 6s) | | |
| 6. Micro SD Card Port | 7. USB Charge Port | |
| 8. Indicator Lights | 9. Radiating Vents | |
| 10. Wifi ON/OFF | | |

Explanation:

AP Mode: Camera connects with phone in phone settings WLAN(for Android) or Wi-Fi(for iPhone); the camera should be close to your phone, or it will be offline and disconnect once you are away;

IP Mode: Set WiFi settings in the APP System settings for network remote viewing; your camera should be close to the router;

Card: Refer to Micro SD card, Max 128G (NOT included);

III. Reset


Once receiving the camera, please fully charge it for 5 hours before use. Then turn it on and press Reset button for 6 seconds for Factory Default Settings.

IV. APP Download

1. Download APP;

Please scan the below QR code and download the apk corresponding with your device (Android/ iPhone/iPad).

You should also download exclusive Video File Player below to playback recording videos saved on the Micro SD card.



2. Hotspot WiFi Connection

1. Connect the camera "CAM-***" in your phone Settings WLAN(or Wi-Fi);

Note: Andriod phones will receive a notification asking whether to change another available network, please ignore and keep connecting with the camera, or the camera will show OFFLINE and all the following steps will fail;

2. Start the APP and it will auto add it for AP Mode.

3. Set WiFi settings in the APP System settings to keep the camera directly connected with the router for network so that you can remotely view it online. If you don't set this, the camera will show OFFLINE when you are away.

Warm Tips:

If you can't find the camera signal in your phone WLAN list, please long press Reset button for 6 seconds, wait for it reboot and turn on the camera once again.

Besides, please make sure to fully charge the camera becuae low power will also influence camera's WiFi strength and connection.

