

# Accessories

1 Time Angel alarm, 1 manual and 1 MICRO USB.

### Introduction of Button Function

# O Sound Night Lamp/ Timing Night Button / Snooze Button

Short press the button and the sound night lamp will turn on.

There will be a logo of • on the sreceen. Press • again to turn off.

### Timing Night Light On/ Off

Long press the button for two seconds and the screen display (LE30) light will be on. Tap lightly to turn off the light.

Press the button in alarm mode to enter into snooze function.

### Sleep Training Mode Button

Long press the button for two seconds and there will be the sleep training function display (L1-Off/L1 On).

There will be a **Z** on the screen. Tap the button lightly to check the sleeping training settings.

### Alarm Setting Button

Long press the button for two seconds to enter into the alarm setting mode and short press it to check the alarm settings.

### Setting Button/ Time Setting Button

Long press the button for two seconds to enter into the time setting and short press to check the date and the temperature.

### ► +Button/ Temperature Shift Button/DP1 DP2 Display Shift Button

**+Button:** Short press the button in setup mode to adjust the date and time.

**Temperature Shift Button:** Short press this button in non-setup mode to shift between the Fahrenheit degree and Celsius

DP1 DP2 Display Shift Button: In the non-setup mode, long press the button for two seconds (The screen will display DP1) and time will appear on the screen. Press again for another two seconds (the screen will display DP2), time, date and temperature will on the screen.

### ■ One-click/Countdown Button

One-click: Short press the button under setup mode to adjust the date and time.

Countdown Button: Long press the button under non-setup mode for two seconds to countdown and press it to exit.

### Instructions for Use

# How to activate the product

1. Please electrify to activate the product for the first time.

### Charging Method and Battery Indication

There is a built-in polymer lithium battery in the alarm. Please use DC5V-1A adapter, portable power or computer USB end to charge. Put the USB connecting wire in the MICRO faucet of the product and connect another end to the adaptor, mobile portable power or USB port. •••• will flash when it's in low battery status. •••• in sommally on during the whole charging process and off when it's fully charged.

### Alarm Display Mode

**Normally-on mode:** When it's connected to external USB powe supply, the display screen is normally on.

Energy-saving mode: When not connected to external power, it will enter into energy-saving mode, with the display screen turning off. Tap to wake up and the display screen will be on after 20 seconds.

### Snoozing function

When the alarm goes off, please tap ② button to suspend the alarm temporarily and enter into the snoozing function. When the snoozing expression is on and glows for five minutes, the alarm will go off again. Tap ② to temporarily suspend the alarm. The function can be used for only three times at once. After a 3-minute alarming, the snoozing function will exit automatically.

### Temperature Display Range

Celsius degree – from 20 degrees to 50 degrees, Fahrenheit degree – from 4 degrees to 122 degrees.

### Sound Night Lights

From 18:00 to 07:00, if the sound night light is on, it will go off after 20 seconds.

### Setting Instructions


### 1.Time Setting

1、Long press to enter into the time setting status. It is in the turn of "years→ months→ days→12/24 hours→ time→minutes→ key tone ON/OFF→screen brightness adjustment 1-3."

Time Setting: Long press to set the year(20-) and it will flash,

# press to adjust. Then press to set the month, which will flash then and press to set 12/24 hour display mode and press to choose. Then press and time will flash, press or bo adjust. Then press and three will be P ON Key tone on /P-- Key tone off. If chosen, press to adjust the brightness of the screen, and press or to adjust the brightness from

2. Under the 12-hour system, the lit AM light means it's in the morning and the lit PM light means it's in the afternoon.




### 2.Alarm Setting

1. Short press 1 to check the alarm setting.
2. Long press 1 for three seconds to set the alarm. The first set of alarm On/Off (ON R1/--R1) sets alarming time. Press 1 or 1 to choose the alarming R1/R2 On/Off. Then press 1 to confirm and press 1 or 1 to set the time on the screen. After confirming the alarming time, press 1 to choose ring type from Monday-Fri-

press ◀ or ▶ to adjust. Then press ₺ to set the month, which will flash then and press ◀ or ▶ to adjust. After adjustment, press ₺ to set 12/24 hour display mode and press ▶ to choose. Then press ₺ and time will flash, press ◀ or ▶ to adjust. Then press ₺ and there will be P ON Key tone on /P-- Key tone off. If chosen, press ₺ to adjust the brightness of the screen, and press ◀ or ▶ to adjust the brightness from

2. Under the 12-hour system, the lit AM light means it's in the morning and the lit PM light means it's in the afternoon.



aay Working Mode/Monday-Saturday Working Mode/Monday-Sunday Working Mode, press ◀ or ▶ to choose. After confirming, press ◀ to choose alarm mush (1-6 sets). Press ◀ or ▶ to adjust the volume (1-5). The setting of the second set of alarm (It is the same as the former one.)

3.Turn off Sleeping Training Setting

Sleep training function is used to cultivate 2 sets of personal living habits including going to bed and getting up.

Start Sleeping Training 1

Close Sleeping Training 1
Long press (3) to enter into sleep training function setting.Press (4) or , the **Z** on the panel display will go off, indicating


esponding settings will appear on the plannel.

Light Changes during Sleeping Training

Once the sleep training is on, the light will last 45 minutes and goes off automatically.


The early training period (from 07:00 to 17:59): The light will change from bright to dark and go off as scheduled.

Sleep training period (from 18:00 to 06:59): The light will change from bright to dark and go off as scheduled.



### 4.Countdown On/Off


1、Long press under non-setup mode to enter into the countdown status and the panel will display "00:30" after ringing once. Press ur to adjust the time and the range is from 1-59 minutes. Countdown will begin after 3-miniute nonoperation. The value displayed on the panel is the time you set and the countdown will start. The countdown ends with a ring for 3 minutes and the music is the same as the alarm.
2、The countdown function is turned off. Under the countdown status, it's from the time to countdown or tap to exit.



### 5.Sound Night Lamp On/Off

Press ① to awaken night light function (from 18:00 to 07:00, the sound night light will be awaken). When it's ON, the sound night light is on and the indicator lighter is normally on. ④ When awoken, the light will go off automatically after 20 seconds. Night light function is close when it's OFF and the night light indicator will go off.

Normally-on mode: When it's connected to external power, the sound control gear will turn into the normally-on night light mode and the voice control function will fail!



### 6.Timing Night Light On/Off

1、Press ② to display the panel. When the "LE 30" flashes for 15 seconds, it will go back to time display automatically. When the panel is flashing, press ▶ to adjust time, with minute as one unit and one unit can be added no more than60 minutes. When the panel is flashing, short press ◀ to lessen the minute and the samllest unit is one minute.

## 2, Press the button again, the night light will be OFF.



### 7. Factory Reset

Click reset button (RESET), the number of 0 to 9 and the indicator light will be lit up in turn. After the marquee, the product will turn off and enter into deep sleep mode, stop working. Only when connected to external USB power, it can be activated.

### Notices

- The operating voltage is DC5V; please use an adapter that meets the national 3C certification standard.
- Do not throw the appliance into fire in case of explosion
- Please don't take it as a toy for children.
- It's not water-proof. Please don't wash it.
  The source of the light is non-replaceable and the entire
- product should be replaced when the product lifecycle ends.

   Please use it on flat surface and prevent tilting!

# se an adapter that Name of Product: Time Angel Alarm dard. No, of Product: XR-MM-C2002

Weight of Product: 200g
Size of Product: 133\*44.5\*115mm

Product Parameter

Product Material: ABS plus PC plus silicone
Rated Power: 1W (84×0.011/LED Module)

Rated Current: 250mA
Rated Voltage: DC5V===

Executive Standard: GB 7000.1-2015 GB 7000.204-2008





