Instructions for HD WIFI Camera

Thank you for purchasing this product, this product has Function include short-range / remote HD real-time monitoring , TF card HD video, loop recording, motion detection, Playback, video recording, recording synchronization.

Application Download

Method 1. Mobile phone of iPhone, search " V380Pro" and download it in "**App Store**".

Method 2. Android phone (include iPhone mobile) scan the following QR code directly to download the application.

To use the device for the first time, initialize the device.

Camera indicator status:

Double lights alternately - search network Long red light - short-range status Blue light is on - remote status Yellow light is on - charging status

When the dual lamp is turned on, it is turned off, and the red light is on for the short-range state. After the remote is set, the blue light is on.

Machine reset and connection

Connect the charger to the machine and gently press the side REST button with a small hard object for about 5 seconds to reset. When reset, the blue light will be on, the red light will flash, and the reset will be successful.

Operation method:

1. download Application First

Short-range use:

Turn on the camera - 30S or so mobile phone search camera WIFI hotspot and connect.

After connecting to the WI-FI hotspot, open the installed “ V380Pro ” software.

Direct AP connection: Directly connected to the login interface does not require login account, click APP “Try without account” to enter, click on the blank space of the page to slide down, and the page automatically adds video.

Registered user account and login:

Register with your mobile phone number and get the verification code. Click “Next” to register. Register and successfully enter your account number and password. Click “Login”.



Set the camera to add:

Click on the device "+" in the upper right corner to select "Access-Point established". On the Back to WIFI Settings page, add a machine hotspot link. Then return to the interface and click "Next" to link the router to enter the password, and the device link is successful.



Function setting:

Click the Settings button to enter the device parameter setting page. There are night vision on the settings page, the image is flipped 180 degrees, the device microphone is turned on/off, the WIFI connected to the device is replaced, the storage settings are set, and the device is restarted/removed.

Computer client viewing camera

Log in to your computer browser and type:
http://as4.nvdvr.cn/client/V380pc.zip Download the computer client tool.

Product parameters:

Video resolution	HD SD
video coding	H.264
Video frame rate	25 frames / seconds
Video format	MP4
storage	Support TF card, maximum extensible to 64G
support system	Windows IOS Android
Charging voltage	DC-5V/1A

Common problem：

fault	processing method
Unable to start	The battery has no electricity, and the battery is open after charging.
Video camera cannot open video on line	Check if network is normal / restart router or restart device.
Can not be remote / remote online	When WIFI is set, pay attention to password errors or special characters.

Matters needing attention：

A) use occasions: Please strictly comply with relevant national laws and regulations, and do not

use this product for any illegal purposes, otherwise the consequences will be conceited.

B) about batteries: long time no use. Please fill the battery before use and charge at least once a month.

C) working temperature: 0 - 45 degrees Celsius, preferably at room temperature.

D) working humidity: 20% - 80% do not put the product in damp working environment, and the product does not have waterproof function.

E) other items: This product belongs to the precision electronic product, please do not cause it to be subjected to strong impact and vibration. Do not use it under strong magnetic field and strong electric field.