


SOLAR WALL LAMP MANUAL

Usage method:

1. When charging the built-in battery, please put the lamp in the position with direct sunlight.
2. Strong sunlight can be converted into solar energy more effectively.
3. Support remote control remote operation, more convenient to use



4. Please turn the power switch to the on position before use, and then press the gear switch or use the remote control to adjust the gear (if the split type product, please connect the solar panel jack)

Mode 1: human body sensing mode (the light is on when a person passes by, and it is off 15 seconds after the person leaves)

Mode 2: human body induction + low light mode (the light will be on when people pass by, and the light will be on again 15 seconds after people leave)

Mode 3: low light mode

Matters needing attention:

1. When using for the first time, place the product in a sunny place for charging for several hours.
2. When the product is not used for a long time, please place the product in a sunny place for charging for 1 day. In order to maintain the function of the battery, it is better to put it in the sufficient sunlight once a month.
3. The charging time and charging efficiency of solar panels may be affected by weather and installation location. Considering the conversion rate of solar power generation, if the product is used in good weather, it will increase the charging efficiency and effectiveness.
4. When there is sunlight and other lights, if the power switch is turned off, the LED light will not be on day and night.
5. The solar lamp should be installed in the place with effective light to ensure that the solar panel can fully absorb the sunlight, so as to extend the working time of the solar lamp.
6. The angle and light direction of the sun lamp should be adjusted to the best position, and the recommended height is 2-3m.
7. In winter or short sunshine time, it is recommended to use solar lamp in mode 1.

