

MANUAL: Thank you for purchasing our product line, in order to make our products to better serve you, please read the instructions carefully before use and retain, to facilitate future maintenance and warranty.

Ultrasonic HUMIDIFIER

Instruction Manual



Fashion • LOVELY • Healthy

EXPERTS SUGGEST

- Use appropriate and white vinegar or Banlangen can effectively remove the harmful bacteria in the air, and the prevention of influenza virus.

Simple operation

The body is horizontally arranged in the appropriate places. Remove water tank, water tank inversion lid of the box, into clean tap water. For convenience will cover is tightly screwed, the water tank is not water leakage shall prevail (without screwing tight). Wipe the water around the glob, installed water tank. Access 220V AC 50Hz power supply, a clockwise turn knob switch, according to production needs to adjust the mist size indicator lights, humidification, humidification quantity can be adjusted, the built-in dream electronic lamp, built-in safety device of automatic protection. When the water tank is not water, sensors to stop working, spray mist spray dry mouth, indicator lights, such as to continue to use, please cut off the power supply. Back to the water tank.

Operation of filling water

unscrew the water tank screw to fill the water



unscrew the water tank screw to fill the water.



- Please use the clean water under 40°C.

Operation note

- Must not be to the water tank and the tank is added with 40°C above the water, in order to avoid discoloration or deformation.
- Do not let water from the outlet flow of human body. The outside of the body of water, use a cloth to clean the.
- In the indoor temperature at 0°C dry circle, please will sink and water in the water poured out, so that the water freezes, result in damaging components.

Product structure



Basic parameters

Rated voltage:
110-220V 50/60Hz
Rated power:
25W @ 35W
Tank capacity: 2-3L
Maximum evaporation:
360mL/H
Noise: <25dB

Maintenance and cleaning

Before cleaning, please be sure to cut off the power, pulling a plug.

Tank cleaning (two to three weeks time)

Unscrew the cap, just a soft cloth to clean the tank man scale, with Shimizu Kiyoshi

Tank cleaning aid (Monday times)

If the tank scale, use a soft cloth dipped in cleaning agent or white vinegar wash, and rinse with water.

External cleaning humidifier

The flexible cloth is below 40 C warm rinse, dry surface stains, the spray nozzle can wash water.

The humidifier collection

The need to clean, dry, returned to the original packaging and stored in dry place.

Warning

Never use the sharp apparatus to touch oscillating transducer, can use soft clean cloth.

Cannot be used with chemical solvents, petrol, kerosene to clean surface.

Don't use detergent to clean. The best use of clean water.

When cleaning, to avoid the water in the water, in order to avoid internal electrical parts wet, malfunction.

Do not use removable body component.

4. Please don't be metal goods, chemicals, such as detergent into the sink, otherwise, will appear the bad atomizing phenomenon.
5. The water in the water tank for a long time, that don't move, otherwise, the overflow of water transported machine will produce fault.
6. Please don't be placed in bright or air humidifier directly irradiated.
7. Don't be humidifier on the air, and as far as possible from the furniture and electrical products.
8. Please don't directly to the body flume water.
9. Is not a long time, please cut off the power, pull the plug.
10. Must not be to do with power to dump out the water remaining in the water, otherwise it will immediately burned transducer.
11. When filled with water can be used continuously for 7-12 hours, not need of adding water.

Safety precautions

1. Please do not use wet hand to pull the plug, so as to avoid electric shock hazard.
2. Body tilt, please cut off the power supply, for further processing.
3. Start, don't touch the transducer, otherwise, will make you pain.
4. Did not cut off the power before, should not be decomposed body, do as to avoid the electric shock accident.
5. That no unauthorized replacement of power line.

Common fault treatment

Abnormal phenomenon	Reason	Processing method
Indicator light does not shine no wind, no fog	At the end of open power switch	Plug the power plug Turn on the power switch
Bright lights, there is no fog wind	To regulate the switch open	To adjust fog quantity switch
Spray fog has peculiar smell	The new machine The water tank is not clean	Open water tank, water tanks will be open In the shade 12 hours The cleaning tank, the replacement of a tank of water
Bright lights, no wind, no fog	Water tank water level too high	Will pour out some water in the sink, tighten the cover.
Spray a small amount	Transducer scaling Dirty water or storing for a long time	Cleaning transducer Replacement of the cleaning water